# MANUAL BIM COMMUNICATION WITH BCF

This manual provides step-by-step instructions for better communication in BIM software **Pillr** with BCF.

BIM Collaboration Format (BCF) is an open standard developed and maintained by buildingSMART International.

These instructions are based on: **Pillr.nl + Pillr for Navisworks 1.4.0 en Pillr for Revit 1.4.1** 



V1.1 25-7-2024

# HOW IN NATIVE SOFTWARE: PILLR

2.4 SHARING

 Issues can be shared through files or cloud based synchronisation.



# 2.4 Sharing (Offline)

In the 'Tasks' tab within the module 'Tasks & Modelcheck' choose at bottom for import or export [1] of tasks. First select to import or export. Then choose BCF from the pull down menu [2] and click next.

• When **importing**; select or use the drag-and-drop function to upload a received BCF or BCFzip file and click on save [3].

**Note**: Make sure that the users match each other, based on email addresses to properly synchronize the tasks on the platform. If an 'assigned to' doesn't match on the platform, the task will be assigned to the person who imported the BCF.

- When **exporting**; choose 'Filter' if a set of tasks must be defined [4]. By attaching a label to each task, filtering will be quick, clearly and easy. Create a BCF file per aspect model, user of another chosen filter.
- Then choose 'Use predefined filters' and/or whether the closed tasks should also be exported. Click on save [5].

# **Creating tasks**

Use the right mouse button in the viewer and select 'Create task' or click on 'Add task' in the 'Task & Modelcheck' module.

8=  $\checkmark$ CAD & Company Model Tasks checke My dashboard 8= 88 12 Show sectionbox MANAGEMENT SETTINGS **BUILD YOUR PROJECTS** Q Filter **BCF** Tutorial #1 INS-W: Replace fire hose ree P Manually created issue Project dashboard Bas van Berkum 1 18-08-22  $\heartsuit$ New Model managemen Documents 目 Elements  $\odot$ Tasks & modelcheck What's new 1 Hide menu C Import/export + Add task Import × O Export FILE 1 Select your file or drag it here. FORMAT Use set filters RCF ~ Including closed inc

3

pillr

2

pillr


5

**Note:** Sharing BCF files in Pillr can only be done in the cloud environment. Pillr works with version 3.0 of the BCF Format.



V1.1 25-7-2024


Hello Bas!



Assign only one person.

三





# HOW IN NATIVE SOFTWARE: PILLR




## 3.1 Naming

Enter the title here [1] with a unique name. Keep this short and to the point.

**Tip:** Agree whether discipline, aspect and/or numbering will be used in the title. Use labels for easy filtering.

# 3.2 Description

Describe clearly what the problem is here [2]. Be clear what is wrong or needs attention and give a suggestion for solving it or how it needs to be solved.




## 3.3 Status

Enter here [3] the status of the task. When creating tasks, always choose 'Active'. The status will change during the process. This is kept in the history of the task.


## **3.4 Responsibilites**

Select here [4] the person responsible to solve the task. If necessary, notify a person who needs to be informed as well.






3.5 OBJECTS



# 3.6 IMAGES The image should represent the issue correctly. Multiple images? Explain each image. Example: image 1: floor clashed with outer wall.



# HOW IN NATIVE SOFTWARE: PILLR



## 3.5 Objects

Select the objects in the viewer. Then create task. The objects are now added automatically.

## 3.6 Images

The image [1] is automatically chosen when the task is created. In the viewer, use the options to create a section and/or hide elements to make the image as clear as possible.


Click on the image to enlarge it when viewing the task. Click on 'Edit image' to edit the image when needed. Optionally, an extra image can be added as 'attachment' or in the 'comment box'.

## 3.7 Comments

Write additional comments here [3] or a comment on the task. When adding an image, a comment is required.

#### 3.7 COMMENTS


- You can add images to support comments.
- A comment is optional, but can clarify the issue and accelerate a positive outcome.






NO PROBLEM WITH BCF!







**BIM COMMUNICATION** 

NO PROBLEM WITH BCF!



3.4 RESPONSIBILITIES Assign who is responsible for resolving

the issue.



3.6 IMAGES The image should represent the issue correctly.

 Multiple images? Explain each image. Example: image 1: floor clashed with outer wall



# HOW IN NATIVE SOFTWARE: PILLR FOR REVIT AND PILLR FOR NAVISWORKS



## 3.1 Naming

Enter the title here [1] with a unique name. Keep this short and to the point.

# 3.2 Description

Describe clearly what the problem is here [2]. Be clear what is wrong or needs attention and give a suggestion for solving it or how it needs to be solved.

## 3.3 Status

By creating tasks within the addin the status is always set on 'Active'. The status will change during the process. This is kept in the history of the task.

# 3.4 Responsibilites

Select here [4] the person responsible to solve the task. If necessary, notify a person who needs to be informed as well.

## 3.5 Objects

Select the objects in the viewer. Then create task. The objects are now added automatically. The number of selected elements are shown here [5].


## 3.6 Images

Add the image [6] with 'make screenshot'. Adjust the screenshot with 'edit screenshot' or an image yourself with 'upload image'.

Tip: Use the other fields to further structure the tasks.

Note: Some fields may not be part of the BCF open standard. These are therefore not included in the synchronization.

Download Pillr for Revit and Pillr for Navisworks. Please note that this is only possible when you are logged in to Pillr.




V1.1 25-7-2024

### 3.7 COMMENTS

#### You can add images to support comments.


 A comment is optional, but can clarify the issue and accelerate a positive outcome.



# HOW IN NATIVE SOFTWARE: PILLR FOR REVIT AND PILLR FOR NAVISWORKS

## 3.7 Comments

Write additional comments here [1] or a comment on the task. When adding an image, a comment is required.



pillr.



V1.1 25-7-2024



This manual has been prepared as an aid, the information communicated in this document is to be used at your own risk. There is no guarantee that the information provided is correct. The author and compiler cannot be held liable for any damage that may result from the use of this document or the application of the advice contained in this document.

Author Pillr: Bas van Berkum (NTI CAD & Company)