Pillr for Revit

Installation manual

Important information

Please make sure that you have sufficient rights to install programs.

1. Installation

Download Pillr for Revit via the Pillr download page. And open the installation file, Pillr_for_Revit_20xx.msi.


2. Steps

See screenshot below for each step:

- a. Welcome and click on Next.
- b. Choose setup and click on Next.
- c. Install setup and click on Next.
- d. Finish setup and click on Finish.

3. Contact

Problems installing Pillr for Revit?
Please contact us via support-nl@nti-group.com




Pillr for Revit

User manual

Important information

Please select "always load" when starting Revit after you installed the add-in.





1. Ribbon

Pillr for Revit can be found in the Revit ribbon.

2. Buttons in ribbon



Pillr:

Settings:


Opens the Pillr panel Settings menu for:

- Language
- Viewer settings
- Log file

Info: How to: About Pillr for Revit Opens FAQ on Pillr.nl

3. Overview

- a. Log in and user account
- b. Select organization
- c. Select project
- d. Bind model to project
- e. Create tasks
- f. View tasks
- g. Publish model to Pillr





1. Create task

Go to "create task" to create manual tasks and publish them to Pillr.

2. Create task overview

- a. Title of task
- b. Create new label or use an existing label
- c. Count of selected elements
- d. Type of task
- e. Priority
- . Assign to
- g. Notify to
- h. Due date selector
- i. Description
- j. Attach a file
- k. Edit, create or upload image
- I. Use "previous" and "next" to toggle between tasks
- m. Create a single task or create multiple tasks and save as a batch





1. View tasks

Go to "View task" to get an overview of all tasks. Get insight in tasks and their status, comments and attachments.

2. Tasks overview

- a. Choose display mode: List or tiles
- b. Refresh and filter tasks
- c. Show task in 2D or 3D

3. Task detail

- d. ID and title
- e. Image (click to view image larger)
- f. Add labels to specify you task
- g. Close task button, only project admin
- h. Use the comment box and communicate about your task

1. Publish

Go to "Publish" to publish your model to Pillr.

2. Steps

See screenshots below for each step:

- a. Create a new project or choose an existing project.
- b. New: fill in the required fields and create a modelgroup.
- Existing: choose correct modelgroup or create a new one
- d. Choose which file format you want to upload:
 .rvt / .ifc* / .nwc**
 - * for IFC you can edit the setup by clicking on "modify setup" **to be able to export to .nwc, the Navisworks NWC Export Utility for Revit has to be installed